

Memory-Map **TECH SUPPORT** **Bulletin #ADV1**

Updating the menu software on the Adventurer 2800

Due to a technical issue with the Adventurer 2800 menu software, Memory-Map may crash upon restarting after the unit has turned off automatically when the auto power down feature is used.

Who requires this update: Adventurer 2800 users who are using V1.24 of the menu software. To find out which version you are using turn on the device and tap **Setting > Information**. The version number will be displayed under **Software Version**. If you have V1.25 or higher you do not need this update.

What this update does: Updates the Adventurer 2800 menu software to prevent Memory-Map failing upon restarting.

To apply the update please follow the instructions below:

- 1.) Download the update from <http://www.memory-map.co.uk/downloads/adv2800/MenuLauncher.exe> and save it to your Desktop or My Documents folder.
- 2.) Turn your Adventurer 2800 on and connect to your PC with the supplied USB cable. Tap the **USB Mass Storage button** on screen to connect to your PC. The 2800 will appear to your PC as two removable drives.
- 3.) Click **Start > My Computer** (Computer in Vista / Windows 7) and this time open the Removable Drive that does not contain the SD card. It can be identified by containing the folders ASIMAP and NANDFLASH.
- 4.) Open the **NANDFLASH** folder and then the **MenuLauncher** folder. Copy the file you saved from step 1 into this folder, overwriting the existing file when prompted.

IMPORTANT: Please make sure you do not make any changes to any other files or folders on this drive.

- 5.) Close all the windows and then disconnect the Adventurer 2800 from your PC. Turn the battery power switch on the left side of the unit to Off and then back to On and turn the unit on as normal.

To confirm the update has been successful tap **Setting > Information** and check the Software Version displayed now is **A2800-Menu:V1.25**.

You can now choose to have the unit automatically power down after a period of inactivity. To do this tap **Setting > Power Save** from the Main Menu and alter the Power Down time accordingly. Please note that your GPS position will not continue to be tracked while the unit is powered down.